

Congratulations!

Congratulations on your new purchase of the appTap. Please follow the steps below to set up your appTap for the first time.

Step 1

Unpack the appTap

Carefully unpack the appTap and retain materials for later use. Please verify that you have the following components:

- appTap Unit
- Two power supplies with cords
- appTap User Guide
- One ethernet cable
- Maintenance Plan if purchased

Step 2 (optional)

Rack Mount the appTap

appTap is designed for rack mounting in a 19-inch equipment rack and occupies one rack unit.


1. Fasten the chassis in place with screws at the front panel ears.
2. Make sure the rack is properly grounded.

Step 3

Connect the appTap to the network

We recommend that the appTap sit between the LAN switch and the WAN router.

1. Connect the switch to Network Port A and the router to Network Port B.
2. Connect the Management Port to the network




Step 4

Power up the appTap

The redundant power connectors can be found at the rear of the unit. Either power connector can power up the unit by itself.

1. Connect a power cord to one of the power connectors.
2. Connect a power supply to the power cord and then to a power outlet.

You can connect both power supplies for high availability.




Step 5

Access the User Interface

Wait for the unit to come up and then check the LCD for the management port's IP address. To access the user interface, open a browser and go to the following address: <http://ip-address> (e.g. <http://10.0.12.7>). You should see the appTap's login page. Use user name **admin** and password **netoptics** to log in.

It is highly recommended that you change the default password.



Recommended Next Steps

Configure the appTap

1. Assign a static IP address
2. Change the unit's name
3. Set time/date
4. Apply your production license key

Please refer to the appTap's User Guide for details on configuring and securing the appTap.

If at any time, you have questions please feel free to contact us by using one of the following methods:

Phone: (408) 737-7777

Email: support@netoptics.com